

Item#
SH-A100, SH-T100

Septic Heater



Prevent Septic System Freeze-Up

- Protects your property & peace of mind
- Two models to choose from
- Easy to install
- Maintenance free
- Three year warranty

Two models to choose from:


A100 Septic Heater – *Is fully automatic, and runs as needed.*

The A100 is perfect for your home away from home. It gives you peace of mind knowing your property is protected.


T100 Septic Heater – *Allows YOU to set the times you want the Septic Heater to run.*

The T100 features the same durability and dependability as the A100. This is a good option if you have the ability to monitor your system periodically.

Gravity System



Mound System



INSTALL:

The goal is to blow warm air into or through the freeze-up spot. Place the Septic Heater downstream of the trouble spot. The heated air will then vent out of the roof sewer vent.

FREQUENTLY ASKED QUESTIONS:

- Q:** How long does it take to install?
A: About 20 minutes or less.
- Q:** How much electricity does it use?
A: It uses 1.2 kw per hour. This equates to about \$1.00 per day in the middle of winter
- Q:** What size pipe does it fit?
A: It fits onto a 4" sdr 35 pipe, but it can be easily adapted to fit other sizes.
- Q:** Won't gases enter the home?
A: No, your traps prevent gases from entering the home.

Where do you freeze?		Where to install.	
A or B	Between the house and tank or in the tank.	Install over the tank.	(1)
C	In the drainfield.	Install over the first drop box in drainfield.	(2)
D	In the lift station or in the mound.	Install over the lift station.	(3)



Water & Wastewater

- Systems
- Products
- Service

(719) 395-6764

Fax: (719) 395-3727

Website: <http://valleyprecast.com/>

Email: frontdesk@valleyprecast.com

28005 County Road 317
 P.O. Box 925
 Buena Vista, CO 81211